

## SOLAR BOX COOKER

## **DESIGN AND INSTRUCTIONS**

Step 1	Instructions and Materials Put each box together (tape up gaps)	
1	• Cardboard Box – 24"x15"x12" (outside box)	
	• Cardboard Box – 22"x14"x10" (inside box)	
	Wide aluminum tape	
	Narrow aluminum tape	
2	Create an insulated platform in the larger box.  • Cardboard Tray 22"x14"x2"	
3	Tape edges and corners of box inside and out to avoid exposed cardboard to oven interior  • Wide aluminum tape  • Narrow aluminum tape	




4	Line each box with foil using adhesive  • Aluminum foil  • Spray adhesive	
5	Construct a lid and pad, line with foil  Cardboard Tray 24"x15"x2"  Cardboard Pad - 24"x16" (for Reflector)  Aluminum foil  Spray adhesive	
6	Put boxes together. Add insulation between them.  • Paper insulation  • Wide aluminum tape	Tradity Constraints of the Const
7	Install glass on lid  • Glass– 20"x14'x 3/16"  • Wide aluminum tape	



8	Paint box interior  Black high-temperature paint - flat black  Blue painters tape for masking edge	
9	<ul> <li>Weatherproof outer cardboard</li> <li>1 Roll of self-adhesive Contact Paper</li> <li>80" of Gorilla Tape</li> </ul>	
10	Install reflector and dowel  • 2 -20' Wood strips 20"  • Wood dowel ¼" x 24"  • Strong Glue	
11	Set Box up for cooking  • Cooling Rack	
	Black Pot	
	<ul><li>Oven Thermometer</li><li>Tray liner</li></ul>	



## Side View





## Top View

